

TERRAIN TAMER 4WD PARTS

INSTRUCTIONS: FRONT DIFFERENTIAL DROP KIT

Application – Toyota Prado – 120 150

(Refer current catalogue for complete listing)

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Install Guide

1. Raise vehicle evenly and safely support.

Note – you possibly can access front Diff mounts without lifting vehicle – Depending on vehicle height.

2. Proceed by removing front bash plate.
3. Using a Jack, support the Diff, then remove the 2 x front mount bolts – slowly lower Diff
4. Place 2 x 25mm spacers in position – refer image below. Use supplied new flat washers and bolts/nuts – tighten.
5. Re-fit Bash plate with 4x spacers – tightened supplied M8 bolts and spring washers.

Contents

- Diff spacers x 2
- Bash plate spacers x 4
- M12 bolts x 2
- M12 nyloc nuts x 2
- Flat washers x 4
- M8 bolts x 4
- Spring washers x 4



Front aluminium spacers



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.